


## 8.0 Booster Car Seat Installation and Use



- If the vehicle seat back is adjustable, adjust vehicle seat back into the upright position or the position specified in the vehicle's owner's manual for use with a Booster Car Seat.
- Thread shoulder belt into the inner slot of Booster Shoulder Belt Guide located on the underside of the Head Support.
  - Slide shoulder belt into open end of slot, around Belt Retainer Tab and into Inner Slot of Head Support.



**NOTE:** Vehicle shoulder belt must slide freely in inner slot of Booster Shoulder Belt Guide.

- Place child in Highback Booster Car Seat with child's back and rump contacting seating surfaces.
- Pull the vehicle Lap/Shoulder Belt across front of child and under both Armrests. Buckle vehicle seat belt.
  - Vehicle Shoulder Belt on buckle side must be under Armrest.
  - Position Vehicle Lap Belt under Armrests and low on hips, contacting top of thighs.
  - Position Vehicle Shoulder Belt across chest and shoulder.

